

## **How to use the Electronic Lock**

### **\*How to Use**

The initial number at the time of purchase is \* 1 2 3 #.

1. Press \* first. (There is a "beep" sound while red light is being turned on)
2. Press 1 2 3. (There is a "beep" sound with the red light)
3. Press #. (it begins to operate with the green light on.)

### **\*How To Close**

Press # (It begins to operate with the green light  
(In case of the door does not operate with force, there is a beep sound three times interval of 10 seconds.)

### **\*How to change Auto/Manual mode (manual mode is initially set)**

1. press \*, password, # (after green light is off)
  - A. Manual mode is operating (press # to close)  
Press 7 and press # (red light is on with beep sound twice)
  - B. Switch operating case (Press # to close)
  - C. Auto mode is operating (at first, automatically close at 20 second)  
(if does not close, automatically closed after 1 minute)  
Press 9 and press # (red light is on with beep sound 4 times)

### **\*How to change the passwords**

The password can be inputted from the figure from 1 unit to up to 15 units

- 0 - Auxiliary Master (All password can be changed)
- 1 - General (The password of one can be changed)
- 2 - General (The password of one can be changed)
- 3 - General (The password of one can be changed)
- Switch - General (The password of one can be changed)

### **\*How to change the switch password**

1. Press the change switch located in the case. (A "beep" sounds with the green light turning on.)
2. (While the green light is on) Press \* and the new password and press #.
3. The procedure is completed with the sound of beep, beep, beep.

### **\* TEST (Do not dose the door)**

\* Press the new password, #.

(The number is well inputted if the green light is on.

It is wrongly inputted if the red light is on with the beeping sounds that the changing switch is pressed again and input is made.)

### **\*How to insert the auxiliary master number**

1. \* Press the currently using password #. (After the green light is off)
2. Press 0 #.
3. (While the green light is on) Pres the new master number and press the # key.
4. The procedure is completed with the beeping sounds.

### **\* TEST (Do not dose the door)**

\* Press the new auxiliary master password #.

(The number is well inputted if the green light is on.

**KGB**  
**Security Services**  
www.kgbsecurity.com.au